

- Выбор запчасти

		Violet, Cod. b		
148	A 0035451301	FUSE BOX, Black, Cod. a	NB	
149	A 0045452905	RELAY, Horn	001	
149	A 0025421419	RELAY, Windshield wiper step control	001	
149	A 0025422619	RELAY, Circuit 15r	001	
150	A 0019847829	SCREW, Mounting, fuse box, M5x25	003	
160	N913023008003	NUT, Battery cable	001	
160	N913025008000	NUT, Starting cable	001	
170	A 1299974981	GROMMET, E-box Комплектация: MC1 /MC2 /MC3 /MC5 /MP1 /MP2 /MP3	003	
170	A 1299974981	GROMMET, E-box Комплектация: MC8 /MG0 /MC9	004	
180	A 6398270088	INSULATION, E-box	001	
190	A 6389880681	PROTECTIVE CAP, M8	001	
195	N000000000458	SHEET METAL SCREW, Sam/srb top	001	
200	A 6395450201	CENTRAL ELECTRICAL SYSTEM, Sam (min)	001	
200	A 6395450301	CENTRAL ELECTRICAL SYSTEM, Sam (max) Комплектация: F46 /L84 /T19 /W32 /EE9 /E28	001	
230	A 0255452832 Замена: A 0005453516 A	PRE-GLOW TIME RELAY, In engine compartment Комплектация: MC1 /MC2 /MC3	001	004 014 525
230	A 0005453516	PRE-GLOW TIME RELAY, In engine compartment Комплектация: MC1 /MC2 /MC3 /MP1 /MP2 /MP3	001	
240	A 6394460017 Замена: A 6394460117 A	CONTROL UNIT, Pneumatic suspension Комплектация: CLO	001	004 015
240	A 6394460117 Замена: A 6394460217 A	CONTROL UNIT, Pneumatic suspension Комплектация: CLO	001	
240	A 6394460217	CONTROL UNIT, Pneumatic suspension Комплектация: CLO	001	016
240	A 6394460317	CONTROL UNIT, Pneumatic suspension Комплектация: CLO	001	017
250	A 6385450119	ADAPTER FRAME, Control unit Комплектация: CLO	001	
260	A 6385450740	HOLDER, D-pillar, right Комплектация: CLO	001	
270	N910001004105	RIVET, Bracket mounting Комплектация: CLO	001	
280	N910112006003	NI IT	003	

		Pre-glow time relay, M6 Комплектация: -G40 +MC1 /-G40 +MC2 /-G40 +MC3		
290	A 1121535079 Замена: A 1121534379 A	CONTROL UNIT, Gasoline vehicles Комплектация: MC7	001	004 018 429 525
290	A 1121534379	CONTROL UNIT, Gasoline vehicles Комплектация: MC7 /MG0	001	019 429 525
290	A 1121537579	CONTROL UNIT, Gasoline vehicles Комплектация: MC7 /MG0	001	020 021 525
290	A 1121538279	CONTROL UNIT, Gasoline vehicles Комплектация: MG0	001	022 429
290	A 1121534979	CONTROL UNIT, Gasoline vehicles Комплектация: MC8	001	429 525
290	A 1121537479	CONTROL UNIT, Gasoline vehicles Комплектация: MC8	001	021 525
290	A 1121538179	CONTROL UNIT, Gasoline vehicles Комплектация: MC8	001	022 429
290	A 2721538279	LU CONTROL UNIT, Msg Комплектация: MC9	001	429 672
290	A 2721538491	LU CONTROL UNIT, Msg Комплектация: MB5 +MC9	001	429 672
295	A 0009930860	BALL PIN, Engine control module Комплектация: MC9	004	
300	A 6461509578 Замена: A 6461509478 A	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC1 +MS3	001	004 023 429 525 672
300	A 6461509478	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC1 +MS3	001	021 429 525 672
300	A 6461501291	CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC1 +MS3	001	022 429 525 672
300	A 6421501377 Замена: A 6421503277 A	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC5	001	004 024 429 525 672
300	A 6421503277 Замена: A 6421509677 A	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC5	001	004 025 429 525 672
300	A 6421509677	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC5	001	026 429 672
300	A 6421500972	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC5	001	027 429 525 672
300	A 6111535179 Замена:	CONTROL UNIT, Diesel vehicles	001	004 028 429 ---

	A 6461503578 A	Комплектация: MC1 +MF8		043 672
300	A 6461503578 Замена: A 6461503378 A	LU CONTROL UNIT, Diesel vehicles, Msg; fuer et und scn-codierung erforderli Комплектация: MC1 +MF8	001	004 029 429 525 672
300	A 6461503378	ZB CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC1 +MF8	001	429 525 672
300	A 6461509991 Замена: A 6461501778 A	CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC2 +MS3	001	004 030 429 525 672
300	A 6461501778	CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC2 +MS3	001	021 429 525 672
300	A 6461501191	CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC2 +MS3	001	022 429 525 672
300	A 6461503278	ZB CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC2 +MF8	001	022 429 672
300	A 6461503478	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC2 +MF8	001	429 525 672
300	A 6461503078	ZB CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC2 +MF4	001	429 525 672
300	A 6461536879 Замена: A 6461501678 A	CONTROL UNIT, Diesel vehicles Комплектация: MC3 +MS3	001	004 031 429 525 672
300	A 6461501678	CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC3 +MS3	001	021 429 525 672
300	A 6461501091	CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC3 +MS3	001	022 429 525 672
300	A 6111534979 Замена: A 6461532791 A	CONTROL UNIT, Diesel vehicles Комплектация: MC3 +MF8	001	429 525 672
300	A 6461532791	CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC3 +MF8	001	032 429 525 672
300	A 6461500791	CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC3 +MF8	001	033 021 429
300	A 6461503178	ZB CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC3 +MF8	001	022 429 672
300	A 6111535579 Замена: A 6461502978 A	CONTROL UNIT, Diesel vehicles Комплектация: MC3 +MF8	001	004 021 429 525

300	A 6461502978	ZB CONTROL UNIT, Diesel vehicles, Msg Комплектация: MC3 +MF4	001	429 525 672
300	A 6461502878 Замена: A 6461507477 A	ZB CONTROL UNIT, Diesel vehicles, Msg Комплектация: KA1 +MC2 +MF4	001	004 034 429 672
300	A 6461507477	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: KA1 +MC2 +MF4	001	429 672
300	A 6461504591	CONTROL UNIT, Diesel vehicles Комплектация: KA1 +MC3 +MF4	001	035 429 525 672
300	A 6461502778 Замена: A 6461507377 A	ZB CONTROL UNIT, Diesel vehicles, Msg Комплектация: KA1 +MC3 +MF4	001	036 004 035 429 672
300	A 6461507377	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: KA1 +MC3 +MF4	001	036 429 672
300	A 6461502678	ZB CONTROL UNIT, Diesel vehicles, Msg Комплектация: KA1 +MC2 +MF4 +ZG2 /D03 +KA1 +MC2 +MF4	001	037 429 672
300	A 6461502578	ZB CONTROL UNIT, Diesel vehicles, Msg Комплектация: KA1 +MC3 +MF4 +ZG2 /D03 +KA1 +MC3 +MF4	001	429 672
300	A 6461500778 Замена: A 6461500777 A	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: KA1 +MF4 +MP2	001	004 026 429 525 672
300	A 6461500777	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: KA1 +MF4 +MP2	001	429 525 672
300	A 6461500878 Замена: A 6461501077 A	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: MF4 +MP2	001	004 026 429 525 672
300	A 6461501077	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: MF4 +MP2	001	429 525 672
300	A 6461500978 Замена: A 6461500677 A	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: KA1 +MF4 +MP3	001	004 026 429 525 672
300	A 6461500677	LU CONTROL UNIT, Diesel vehicles,	001	429 525

		Msg Комплектация: KA1 +MF4 +MP3		672
300	A 6461501078	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: MF4 +MP3	001	026 429 525 672
300	A 6461500977	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: MF4 +MP3	001	027 429 525 672
300	A 6461505178	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: D03 +KA1 +MF4 +MP1	001	026 429 525 672
300	A 6461501477	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: D03 +KA1 +MF4 +MP1	001	027 429 525 672
300	A 6461505078	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: D03 +KA1 +MF4 +MP2	001	026 429 525 672
300	A 6461501377	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: D03 +KA1 +MF4 +MP2	001	027 429 525 672
300	A 6461504978	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: D03 +KA1 +MF4 +MP3	001	026 429 525 672
300	A 6461501277	LU CONTROL UNIT, Diesel vehicles, Msg Комплектация: D03 +KA1 +MF4 +MP3	001	027 429 525 672
302	A 2035400681	PLUG SOCKET, Control-unit plug-connection, 96-fach;n3/9	001	
304	A 0155452326	CONTACT SPRING	NB	
304	A 0155452426	CONTACT SPRING	NB	
304	A 0155452926	CONTACT SPRING	NB	
304	A 0155453026	CONTACT SPRING	NB	
304	A 0155453226	CONTACT SPRING	NB	
304	A 0005458480	GASKET	NB	
304	A 0005457980	GASKET	NB	
306	A 2035400581	PLUG SOCKET, Control-unit plug-connection, 58-pin;n3/9	001	
306	A 0015459483	CAP, N3/9	001	
308	A 0095458026	CONTACT SPRING, 0.25-0.5 mm2	NB	
308	A 0095458126	CONTACT SPRING, 0.75-1.0 mm2 slk2.8	NB	
308	A 0095458226	CONTACT SPRING, 1.5-2.5 mm2 slk2.8	NB	
308	A 0005457180	GASKET, 0.25-1.0 mm2	NB	
308	A 0005457680	GASKET, 1.5-2.5 mm2	NB	
308	A 0015453080	GASKET, 1.5-2.5 mm2	NB	
308	A 0005457880	DUMMY PLUG	NB	
308	A 0135451626	CONTACT SPRING, 1.5-2.5 mm2 slk	NB	
308	A 0195452526	CONTACT SPRING, 0.22-0.5 mm2	NB	

308	A 0195452626	CONTACT SPRING, 0.75-1.0 mm2	NB	
310	A 0305450832 Замена: A 0325452832 A	CONTROL UNIT, Automatic transmission Комплектация: G40	001	
310	A 0325452832 Замена: A 0325453832 A	CONTROL UNIT, Automatic transmission Комплектация: G40	001	
310	A 0325453832	CONTROL UNIT, Automatic transmission Комплектация: G40 /G40 +MC8	001	
310	A 0005458216 Замена: A 0005458416 A	CONTROL UNIT, Automatic transmission, Gsg Комплектация: G40 +MC5	001	004 038 672
310	A 0005458416	LU CONTROL UNIT, Automatic transmission, Gsg Комплектация: G40 +MC5	001	672
310	A 0005458516	LU CONTROL UNIT, Automatic transmission, Gsg Комплектация: G40 +MP2 /G40 +MP3	001	039 672
310	A 0005458516	LU CONTROL UNIT, Automatic transmission, Gsg Комплектация: G40 +MC5 /G40 +MP2 /G40 +MP3	001	040 672
310	A 0005458916	LU CONTROL UNIT, Automatic transmission, Gsg Комплектация: G40	001	041 672
310	A 0345451832	CONTROL UNIT, Automatic transmission Комплектация: G40 +MG0	001	
330	A 0025421419	RELAY, Heated rear window Комплектация: W61 /W78	001	
330	A 0025421419	RELAY, Headlamp cleaning system Комплектация: F46	001	
330	A 0025422619	RELAY, Secondary air pump Комплектация: MC7 /MC8 /MG0	001	
350	N000000000595	FUSE, Prefuse box, Mbn-10198-sf51-150 amp.	001	042
350	N000000000598	FUSE, Prefuse box, Mbn 10198-sf51-225 amp.	001	043
380	A 6398200026	CONTROL UNIT, Left front door	001	
380	A 6398200326	CONTROL UNIT, Right front door	001	
400	A 0385451328	PLUG HOUSING, Window regulator, 7-pin;n69	001	
405	A 0005404505	REP.SET CONTACT, 0.5 mm2 mqs	NB	007
405	A 0135457626	CONTACT BUSHING, 0.5-1.0 mm2 mcp	NB	
410	A 0375456328	PIN BUSHING HOUSING, Infrared, 3 pin;n69	001	
420	A 0385457228	PLUG, Central locking mechanism, 6-pin;n69	001	
425	A 0005404605	REP.SET CONTACT, 0.75 mm2 mqs	NB	007

430	A 0385457128	PLUG HOUSING, Heated outside rearview mirror, 6-pin;n69	001	
430	A 0385457128	PLUG HOUSING, Mirror camera, 6-pin;n69 Комплектация: ZJ1	001	
435	A 0165454126	CONTACT SPRING, Mirror camera, 0.25-0.5 mm2 mqs Комплектация: ZJ1	NB	
435	A 0085455526	CONTACT BUSHING, Mirror camera, 0.75 mm2 mqs Комплектация: ZJ1	NB	
440	A 0345457528	PLUG HOUSING, Folding outside rearview mirror, 8-pin;n69	001	
450	A 0375455928	PIN BUSHING HOUSING, Courtesy lamp, 2-pin;n69	001	
450	A 0055404081	TS SOCKET PARTS KIT, Mirror camera, 8-pin/n69 Комплектация: ZJ1	001	
470	A 0375456528	SOCKET HOUSING, Window regulator, 4 pin;n69	001	
480	A 6395450032	CONTROL UNIT, Electric sliding/lifting roof Комплектация: D27 +ZK0 /D27 +ZK9	001	
480	A 6395450032	CONTROL UNIT, Tilting/sliding roof, in rear Комплектация: D24	001	
483	N000000000521	SHEET METAL SCREW, Control unit fixture, 4.2x13 Комплектация: D24	001	
490	A 0315457232	CONTROL UNIT, Hitching mechanism Комплектация: Q22 /Q50 /EC7	001	046
490	A 1695452032 Замена: A 1695453932 A	CONTROL UNIT, Hitching mechanism Комплектация: Q22 /Q50 /EC7	001	047
490	A 1695453932	CONTROL UNIT, Hitching mechanism Комплектация: Q22 /Q50 /EC7	001	047
500	A 0355455132	CONTROL UNIT, Blinker lamp,rear end,top Комплектация: L84	001	
505	A 6385450119	ADAPTER FRAME, Right rear inside pillar Комплектация: L84	001	
510	A 6385450740	HOLDER, Control unit Комплектация: L84	001	
515	N910001004105	RIVET, Bracket to pillar Комплектация: L84	001	
520	A 0039947945	SPRING NUT, Control unit fixture Комплектация: Q22 /Q50 /EC7	002	
530	N914127003216	SHEET METAL SCREW, Control unit fixture, 3.5x16 Комплектация: Q22 /Q50 /EC7	002	

540	A 0005468935	PROTECTIVE CAP, Jump-starting point	001	
545	A 2105410072	NUT, Jump start negative terminal	001	
550	A 0015454840	PIN BUSHING HOUSING, Sam electrical center, 18-pin;n10.1	001	
550	A 0005459103	COVER, To 001 545 48 40	001	
550	A 0005454230	HOUSING, To 001 545 48 40	001	
570	A 0375455728	PIN BUSHING HOUSING, Fuse/relay box, 12-pin;k40/9	001	
580	A 0135451426	CONTACT SPRING, 0.25-0.5 mm2 slk	NB	
580	A 0135451526	CONTACT SPRING, 0.75-1.0 mm2 slk	NB	
600	A 0085455526	CONTACT BUSHING, Fuse/relay box, 0.75 mm2 mqs;k40/9	NB	
610	A 1635453528	FUSE BOX, Fuse/relay box, 2-pin;k40/9	001	
620	A 0115458426	CONTACT SPRING, 0.5-1.0 mm2 spt;to 003 545 13 01	NB	
620	A 0115458126	CONTACT SPRING, 0.5-1.0 mm2 jpt;to 163 545 35 28	NB	
620	A 0045450026	CONTACT SPRING, Fuse/relay box, 4.0 mm2 spt;k40/9-f21; k40/9- f32; k40/9-	NB	
630	A 0375456728	PLUG, Door control unit power supply, 7 pin;n69	001	
640	A 0135457826	CONTACT BUSHING, 1.5-2.5 mm2 mcp	NB	
650	A 2205455428	PIN BUSHING HOUSING, Sam electrical center, 2 pin;n10.8	001	
670	A 0335451028	HOUSING, Sam electrical center, 3-pin;n10.4	001	
690	A 0015454940	PLUG HOUSING, Sam electrical center, 28-pin;n10.3	001	
690	A 0015450883	CAP, To 001 545 49 40	001	
710	A 2205453428	PIN BUSHING HOUSING, Fuse/relay box, 10-pin;k40/9	001	
720	A 0115450726	CONTACT SPRING, 2.5-4.0 mm2 slk	NB	
720	A 0095452526	CONTACT SPRING, 6.0-10.0 mm2	NB	
730	A 1685450128	PIN BUSHING HOUSING, Fuse/relay box, 1-pin;k40/9	001	
750	A 0025408681	PLUG HOUSING, Sam electrical center, 14-pin;n10.6 Комплектация: W32	001	
750	A 2085450730	COVER, N10	001	
760	A 0085455526	CONTACT BUSHING, 0.75 mm2 mqs Комплектация: W32	NB	
770	A 0365455528	PLUG HOUSING, 5-pin;k40/9	001	
770	A 0005453930	COVER, K40/9	001	
775	A 0165454126	CONTACT SPRING, 0.25-0.5 mm2 mqs	NB	
780	A 2105450140	PLUG HOUSING, Control module for electronic transmission control, 12-pin;n15/3	001	
780	A 2105451328	PLUG HOUSING, Control module for electronic transmission control, 2-pin;n15/3	001	
780	A 2105450703	COVER, To 210 545 01 40/13 28	001	
800	A 2105450040	PLUG HOUSING, Control module for electronic transmission control, 18-pin;n15/3	001	
800	A 2105450403	COVER, To 210 545 00 40	001	
820	A 0135456526	PIN BUSHING HOUSING, Additional flasher module, 21-pin;n9/1 Комплектация: L84	001	

830	A 0135457626	CONTACT BUSHING, 0.5-1.0 mm2 mcp Комплектация: L84	NB	
840	A 0305457628	SOCKET HOUSING, Sam electrical center, 3 pin;n10.5 Комплектация: L84	001	
850	A 0005404505	REP.SET CONTACT, 0.5 mm2 mqs Комплектация: L84	NB	007
860	A 0385451228	PLUG HOUSING, Sam electrical center, 4-pin;n10.11	001	
880	A 0375455528	PLUG, Sam electrical center, 8-pin;n10.7	001	
900	A 0405457928	PLUG, Fuse/relay box, 8-pin;k40/9	001	
920	A 2205451928	PIN BUSHING HOUSING, Sam electrical center, 20 pin;n10.9	001	
933	A 1685450928	HOUSING, Control-unit plug-connection, 40-pin;n3/10.4	001	
936	A 0055457526	CONTACT SPRING, 0.25-0.5 mm2 mqs	NB	
939	A 2205459528	HOUSING, Control-unit plug-connection, 9-pin;n3/10.5	001	
942	A 0115458026	CONTACT SPRING, 1.5-2.5 mm2 jpt	NB	
945	A 0015454740	PIN BUSHING HOUSING, Fuse/relay box, 12-pin;k40/9	001	
951	A 0085451526	PIN BUSHING HOUSING, Relay base, 4-pin;k64 Комплектация: MC7 /MC8 /MGO	001	
951	A 0075459226	RELAY SACKET, Headlamp wiper/washer relay, 9-pin;k2 Комплектация: F46	001	
954	A 0045450026	CONTACT SPRING, 4.0 mm2 spt Комплектация: F46	NB	
954	A 0045455226	CONTACT SPRING, 1.0-2.5 mm2 spt Комплектация: F46	NB	
957	A 0025454201	FUSE BOX, "maxi"; f5	001	409
960	A 0125450426	CONTACT SPRING, 4.0 mm2	NB	
963	A 2105402181	PIN BUSHING HOUSING, Pre-glow time relay, 3 pin;n14/2	001	
966	A 0085456326	CONTACT BUSHING, 0.75 mm2, mqs	NB	
966	A 0005456980	GASKET, 1.6-1.9 mm2	NB	
966	A 0005458780	DUMMY PLUG	NB	
969	A 0325452128	PIN BUSHING HOUSING, Sam electrical center, 2-pin;n10.10	001	
974	A 0025409581	PLUG HOUSING, Control unit trailer recognition, 14-pin;n28/1	001	
978	A 0375453528	SOCKET HOUSING, Control unit trailer recognition, 6 pin;n28/1	001	046
978	A 0025407581	PIN BUSHING HOUSING, Control unit trailer recognition, 8-pin;n28/1	001	047
982	A 0135456526	PIN BUSHING HOUSING, Air suspension control module, 21-pin;n51/3	001	